



Acer Iconia Tab 8 A1-840 Rear Camera Replacement

This easy how-to guide will detail the removal of the rear facing camera on your Acer Tablet.

Written By: Steven Gontarz



INTRODUCTION

The camera is one the simplest components to replace once the back cover is removed. The important thing to remember here is to take your time removing the cover.



TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Heavy-Duty Spudger](#) (1)
 - [Precision Tweezers Set](#) (1)
-

Step 1 — Back Panel



- Power off the device
- Remove any cables that might be connected to your device
- Make sure the device is placed on a flat surface with the display screen facing up

Step 2



- Wedge the plastic opening tool in between the display screen and back panel
- ⚠ Do not apply too much pressure in order to avoid cracking the screen

Step 3




- Carefully separate the display from the back panel

Step 4 — Rear Camera



- Use the flat end of the spudger to gently open the black flap.

Step 5



- Use the precision tweezers to carefully pull out the connector and remove the camera.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-04 07:14:17 AM.